6-2D-LM65-041 Rev.00

# Φ10.5mm 650nm Laser Module

### **Features**

APC (auto power control) IC inside Low current consumption of the APC circuit Surge current protection High quality lens for output beam



## Absolute maximum ratings

Parameter	Symbol	Rating	Unit
Power supply voltage	Vcc	3.3	V
Laser Module optical output power	Ро	<5	mW
Operation temperature	Topr	-5~50	°C
Storage temperature	Tstg	-20~70	°C


# Electrical and optical characteristics (T<sub>c</sub>=25 °C)


Parameter	Symbol	Min.	Тур.	Max.	Unit	Conditions	
Wavelength	λ	-	655	-	nm	Po= 5mW	
Operation current	lop	-	-	35	mA	Po= 5mW ; Vcc=3V	
Optical output power	Pout	3.7		5	mW		
Operation voltage	Vop	2.5	-	3.3	Volt		
Laser Beam spot size at 10m	<8mm						
Divergence angle	0.9 mrad						

<sup>\*</sup> Sufficient heat dissipation is required for CW operation.

## Outline dimensions (Units: mm)







Aperture Size: 5mm



PHONE: 886-3-4699800 | FAX: 886-3-4699600

E-MAIL: Ldsales@arimalasers.com | www.arimalasers.com | For reference only. Contents above are subject to change without notice.




6-2D-LM65-041 Rev.00


# Ф10.5mm 650nm Laser Module

## Instruction manual


DC Power connection mode 1

A type: Heat sink stand (-)





#### DC Power connection mode 2



- Do not operate the device above maximum ratings. Doing so may cause unexpected and permanent damage to the device.
- Take precautions to avoid electrostatic discharge and/or momentary power spikes. A change in the characteristics of the laser or premature failure may result.
- Proper heat sinking of the device assures stability and lifetime. Always ensure that maximum operating temperatures are not exceeded
- Observing visible or invisible laser beams with the human eye directly, or indirectly, can cause permanent damage. Use a camera to observe the laser.
- No laser device should be used in any application or situation where life or property is at risk in event of device failure.

  Specifications are subject to change without notice. Ensure that you have the latest specification by contacting us prior to purchase or use of the product.

#### ARIMA LASERS CORP.

PHONE: 886-3-4699800 | FAX: 886-3-4699600 E-MAIL: Ldsales@arimalasers.com | www.arimalasers.com

